

Active & Diode Parts Handling

Provided Equipment:

- ESD Handling Gloves
 - Only the fingertips are coated in the protective material
- ESD Wristband
 - Must be clipped to a rubber mat
- ESD Rubber Mat
- ESD Silver Bags
 - Only the inside of the bags are ESD safe
- ESD Pink Bubble Wrap
 - Only the inside of the bags are ESD safe

General good practice before handling ESD sensitive parts:

- Touch a metal surface before starting to discharge yourself
- Clip the wristband to the rubber mat
- Wear the wristband around your wrist, the metal side must be touching skin
- Don your ESD handling gloves
- Keep parts in silver bags
- If bubble wrap is needed only the pink ones may be used.
- Active parts cannot be stacked and must only be on flat surfaces

Active and Diode Series

Active Line

SBL	SBP	SBB
SFA	SSR	SST
SSC	STB	

Diode Line

SFB	SFD	SFH	SFP	SFS
SFU	SFV	SKA	SKD	SK8
SKS	SOL	SOM	SSM	SSP
SSS	STD	STE	STG	STH
STZ				